



Operating Instructions **optoNCDT 1220**

ILD 1220-10
ILD 1220-25
ILD 1220-50
ILD 1220-100
ILD 1220-200

ILD 1220-500

Intelligent laser optical displacement measurement

MICRO-EPSILON
MESSTECHNIK
GmbH & Co. KG
Koenigbacher Str. 15

94496 Ortenburg / Germany

Tel. +49 (0) 8542 / 168-0
Fax +49 (0) 8542 / 168-90
e-mail info@micro-epsilon.com
www.micro-epsilon.com

Contents

1.	Safety	9
1.1	Symbols Used	9
1.2	Warnings	9
1.3	Notes on CE Marking	10
1.4	Intended Use	11
1.5	Proper Environment.....	11
2.	Laser Safety	12
3.	Functional Principle, Technical Data	14
3.1	Short Description	14
3.2	Auto Target Compensation (ATC)	15
3.3	Technical Data	16
4.	Delivery	18
4.1	Unpacking, Included in Delivery.....	18
4.2	Storage	18
5.	Installation	19
5.1	Notes for Operation	19
5.1.1	Reflection Factor of the Target Surface	19
5.1.2	Error Influences	20
5.1.2.1	Light from other Sources	20
5.1.2.2	Color Differences	20
5.1.2.3	Temperature Influences	20
5.1.2.4	Mechanical Vibration	20
5.1.2.5	Movement Blurs	20
5.1.2.6	Surface Roughness	21
5.1.2.7	Angle Influences	22
5.1.3	Optimizing the Measuring Accuracy	23
5.2	Mounting, Dimensions	24
5.3	Indicator Elements at Sensor	26

5.4	Electrical Connections.....	27
5.4.1	Connection Possibilities for Parametrization.....	27
5.4.2	Pin Assignment.....	29
5.4.3	Supply Voltage.....	30
5.4.4	Laser on.....	30
5.4.5	RS422 Connection with USB Converter IF2001/USB.....	31
5.4.6	Analog Output.....	31
5.4.7	Multifunctional Input.....	32
5.4.8	Digital Output.....	33
5.4.9	Sensor Cable.....	34
6.	Operation.....	35
6.1	Getting Ready for Operation.....	35
6.2	Parameterizing via Web Interface.....	36
6.2.1	Preconditions.....	36
6.2.3	Access via Web Interface.....	37
6.3	Timing, Measurement Value Flux.....	39
7.	Set Sensor Parameter.....	40
7.1	Preliminary Remarks to the Adjustments.....	40
7.2	Overview Parameter.....	40
7.3	Inputs.....	41
7.3.1	Overview Functions.....	41
7.3.2	Zeroing.....	41
7.3.2.1	Zeroing with Select Key.....	42
7.3.2.2	Zeroing with Hardware Input.....	43
7.4	Signal Processing.....	44
7.4.1	Preliminary Remark.....	44
7.4.2	Measuring Rate.....	44
7.4.3	Error Handling.....	44
7.4.4	Triggering.....	45
7.4.4.1	General.....	45
7.4.4.2	Value Output Trigger.....	46
7.5	Outputs.....	47
7.5.1	Overview.....	47
7.5.2	Digital Output, RS422.....	48
7.5.2.1	Values, Ranges.....	48
7.5.2.2	Characteristics Digital Output.....	49

7.5.3	Analog Output Scaling	51
7.5.3.1	Output Scaling	51
7.5.3.2	Output Scaling with Key Select.....	52
7.5.3.3	Output Scaling via Hardware Input.....	53
7.5.3.4	Calculation of Measuring Value using Analog Current.....	54
7.5.3.5	Characteristics Distance Value and Analog Output.....	56
7.5.3.6	Zeroing and Teaching Analog Output.....	58
7.5.4	Switching Output	59
7.6	System Settings.....	60
7.6.1	General	60
7.6.2	Unit, Language	60
7.6.3	Keylock	60
7.6.4	Load, Save.....	61
7.6.5	Import, Export.....	63
7.6.6	Access Authorization.....	64
8.	Digital Interface RS422	66
8.1	Measurement Data Format.....	66
8.2	Conversion of the Binary Data Format	67
9.	Cleaning.....	67
10.	Liability for Material Defects.....	68
11.	Decommissioning, Disposal	68
12.	Service, Repair	68

Appendix	69
A 1 Optional Accessories	69
A 2 Factory Settings	70
A 3 ASCII Communication with Sensor	71
A 3.1 General	71
A 3.2 Overview Commands	73
A 3.3 Commands	76
A 3.3.1 General Commands	76
A 3.3.1.1 HELP.....	76
A 3.3.1.2 GETINFO, Sensor Information	77
A 3.3.1.3 LANGUAGE, Website	78
A 3.3.1.4 RESET, Boot Sensor.....	78
A 3.3.1.5 ECHO, Switching the Command Reply, ASCII Interface	78
A 3.3.1.6 PRINT, Sensor Settings	79
A 3.3.2 User Level.....	80
A 3.3.2.1 LOGIN, Change of the User Level.....	80
A 3.3.2.2 LOGOUT, Change into User Level	80
A 3.3.2.3 GETUSERLEVEL, User Level Request	80
A 3.3.2.4 STDUSER, Set Standard User	80
A 3.3.2.5 PASSWD, Change Password	80
A 3.3.3 Triggering.....	81
A 3.3.3.1 TRIGGER, Selection	81
A 3.3.3.2 MFILEVEL, Input Pulse Multifunctional Input.....	81
A 3.3.3.3 TRIGGERCOUNT, Number of Displayed Measurement Values	81
A 3.3.4 Interfaces	82
A 3.3.4.1 BAUDRATE, RS422	82
A 3.3.4.2 UNIT, Web Interface.....	82
A 3.3.4.3 MFIFUNC, Function Selection Multifunctional Input.....	82
A 3.3.4.4 ERROROUT1, Activate Error Output.....	82
A 3.3.4.5 ERRORLEVELOUT1, Output Level Digital Output	83
A 3.3.4.6 ERRORLIMIT	83
A 3.3.4.7 ERRORHYSTERESIS	83
A 3.3.4.8 ERROROUTHOLD	83

A 3.3.5	Handling of Setups.....	84
	A 3.3.5.1 IMPORT	84
	A 3.3.5.2 EXPORT	84
	A 3.3.5.3 MEASSETTINGS, Load / Save Measurement Settings	85
	A 3.3.5.4 BASICSETTINGS, Load / Save Device Settings.....	86
	A 3.3.5.5 SETDEFAULT, Default Settings	86
A 3.3.6	ANALOGSCALE, Scaling the Analog Output.....	86
A 3.3.7	Key Function.....	87
	A 3.3.7.1 KEYFUNC, Choose Key Function	87
	A 3.3.7.2 KEYLOCK, Set Keylock	87
A 3.3.8	Measurement.....	88
	A 3.3.8.1 MEASRATE, Measuring Rate	88
	A 3.3.8.2 LASERPOW, Laser Power	88
	A 3.3.8.3 MASTERMV, Mastering / Zeroing.....	88
A 3.3.9	Data Output	89
	A 3.3.9.1 OUTPUT, Selection of Measurement Value Output	89
	A 3.3.9.2 OUTHOLD, Error Processing	89
	A 3.3.9.3 GETOUTINFO_RS422, Request Data Selection.....	89
	A 3.3.9.4 OUT_RS422.....	89
	A 3.3.9.5 OUTADD_RS422, Selection of Data Additional Values	90
A 3.4	Error Messages.....	91

1. Safety

Sensor operation assumes knowledge of the operating instructions.

1.1 Symbols Used

The following symbols are used in this operating instructions:



Indicates a hazardous situation which, if not avoided, may result in minor or moderate injury



Indicates a situation that may result in property damage if not avoided.



Indicates a user action.



Indicates a tip for users.

Measure

Indicates hardware or a software button/menu.

1.2 Warnings



Avoid unnecessary laser radiation to be exposed to the human body.



Switch off the sensor for cleaning and maintenance.



Switch off the sensor for system maintenance and repair if the sensor is integrated into a system.

Caution - use of controls or adjustments or performance of procedures other than those specified may cause harm.

Connect the power supply and the display/output device according to the safety regulations for electrical equipment.

> Risk of injury

> Damage to or destruction of the sensor

NOTICE

Avoid shocks and impacts to the sensor.

> Damage to or destruction of the sensor

Mount the sensor only to the existing holes on a flat surface. Clamps of any kind are not permitted.

> Damage to or destruction of the sensor

The supply voltage must not exceed the specified limits.

> Damage to or destruction of the sensor

Protect the sensor cable against damage. Attach the cable load-free, hold the cable after appr. 25 cm e.g. zip tie.

> Destruction of the sensor

> Failure of the measuring device

Avoid constant exposure of sensor to splashes of water.

> Damage to or destruction of the sensor

Avoid exposure of sensor to aggressive media (detergents, cooling emulsions).

> Damage to or destruction of the sensor

1.3 Notes on CE Marking

The following apply to the optoNCDT 1220:

- EU Directive 2014/30/EU
- EU Directive 2011/65/EU

Products which carry the CE mark satisfy the requirements of the EU directives cited and the relevant applicable harmonized European standards (EN). The sensor is designed for use in industrial environments.

The EU Declaration of Conformity and the technical documentation are available to the responsible authorities according to the EU Directives.

1.4 Intended Use

- The optoNCDT 1220 system is designed for use in industrial and laboratory applications.
- It is used
 - for measuring displacement, distance, position and thickness
 - for in-process quality control and dimensional testing
- The sensor must only be operated within the limits specified in the technical data, see Chap. 3.3.
- The sensor must be used in such a way that no persons are endangered or machines and other material goods are damaged in the event of malfunction or total failure of the controller.
- Take additional precautions for safety and damage prevention in case of safety-related applications.

1.5 Proper Environment

- Protection class: IP65 (applies only when the sensor cable is plugged in)

Lenses are excluded from protection class. Contamination of the lenses leads to impairment or failure of the function.

- Temperature range:
 - Operation: 0 °C ... +50 °C (+32 ... +104 °F)
 - Storage: -20 °C ... +70 °C (-4 ... +158 °F)
- Humidity: 5 - 95 % (non-condensing)
- Ambient pressure: Atmospheric pressure

! The protection class is limited to water (no penetrating liquids, detergents or similar aggressive media).

2. Laser Safety

The ILD1220 sensors operate with a semiconductor laser with a wavelength of 670 nm (visible/red). The sensors fall within Laser Class 2 (II). The laser is operated on a pulsed mode, the maximum optical power is ≤ 1 mW. The pulse frequency depends on the adjusted measuring rate (0.25 ... 1 kHz). The pulse duration of the peaks is regulated depending on the measuring rate and reflectivity of the target and can be 0.3 ... 3999.6 μ s.

i Observe the laser protection regulations!

CAUTION

Laser radiation.
Irritation or injury of the eyes possible. Close your eyes or immediately turn away if the laser beam hits the eye.

Although the laser output is low, directly looking into the laser beam must be avoided. Close your eyes or immediately turn away if the laser beam hits the eye. The housing of the optical sensors may only be opened by the manufacturer, see Chap. 10. For repair and service purposes, the sensors must always be sent to the manufacturer.

Lasers of Class 2 (II) are not subject to notification and a laser protection officer is not required.

The following warning labels are attached to the sensor cable.




Fig. 1 Laser labels on the sensor cable



Fig. 2 Laser warning sign on the sensor housing

During operation of the sensor the pertinent regulations according to IEC 60825-1 on „Safety of laser products“ must be fully observed at all times. The sensor complies with all applicable laws for the manufacturer of laser devices.

Laser operation is indicated by LED, see Chap. 5.3.




Fig. 3 Sensor cable and sensor with laser sign, ILD 1220

- i** If both warning labels are covered over when the unit is installed, the user must ensure that supplementary labels are applied.


3. Functional Principle, Technical Data

3.1 Short Description

The optoNCDT 1220 uses the principle of optical triangulation, that is, a visible, modulated point of light is projected onto the target surface.

The diffuse part of the reflection of this point of light is displayed depending on distance on a position-resolving element (CMOS) by an receiver optic which is arranged to the optical axis of the laser beam in a defined angle.

A signal processor in the sensor calculates the distance of the point of light on the measuring object to the sensor by means of the output signal of the CMOS elements. The distance value is linearized and output by means of the analog or RS422 interface.



MR = Measuring range
 SMR = Start of measuring range
 MMR = Mid of measuring range
 EMR = End of measuring range

Fig. 4 Definition of terms

3.2 Auto Target Compensation (ATC)

The Auto Target Compensation (ATC) enables stable compensation independent of color and brightness of the measuring object. Also small objects can be detected reliably thanks to the small measuring spot.

3.3 Technical Data

				Available for OEM series		
Model	ILD1220-10	ILD1220-25	ILD1220-50	ILD1220-100	ILD1220-200	ILD1220-500
Measuring range	10 mm	25 mm	50 mm	100 mm	200 mm	500 mm
Start of measuring range	20 mm	25 mm	35 mm	50 mm	60 mm	100 mm
Mid of measuring range	25 mm	37.5 mm	60 mm	100 mm	160 mm	350 mm
End of measuring range	30 mm	50 mm	85 mm	150 mm	260 mm	600 mm
Measuring rate ¹	3 adjustable stages: 1 kHz / 0.5 kHz / 0.25 kHz					
Linearity	< ±10 μm	< ±25 μm	< ±50 μm	< ±100 μm	< ±200 μm	< ±750 ... 1500 μm
	< ±0.10 % FSO					< ±0.15% ... 0.30 % FSO
Repeatability ²	1 μm	2.5 μm	5 μm	10 μm	20 μm	50 μm
Temperature stability	±0.015 % FSO / K			±0.01 % FSO / K		
Light spot diameter (±10%), [μm]	SMR	90 x 120	100 x 140	90 x 120	750 x 1100	
	MMR	45 x 40	120 x 130	230 x 240		
	EMR	140 x 160	390 x 500	630 x 820		
	smallest Ø	45 x 40 with 24 mm	55 x 50 with 31 mm	70 x 65 with 42 mm	-	
Light source	Semiconductor laser < 1 mW, 670 nm (red)					
Laser safety class	Class 2 in accordance with IEC 60825-1: 2014					
Permissible ambient light ³	20,000 lx				7,500 lx	
Supply voltage	11...30 VDC					
Power consumption	< 2 W (24 V)					
Analog output	4 ... 20 mA (12 bit, freely scalable within the measuring range) ⁴					

Digital interface	RS422 (16 bit)	
Switching output	1 x error output: npn, pnp, push pull	
Connection	integrated cable 2 m, open ends, minimum bending radius 30 mm (fixed installation)	
Mounting	Screw connection via two mounting holes	
Temperature range	Operation	0 ... +50 °C (+32 ... +122 °F) (non-condensing)
	Storage	-20 ... +70 °C (-4 ... +158 °) (non-condensing)
Shock (DIN-EN 60068-2-29)	15 g / 6 ms in 3 axes, 1000 shocks each	
Vibration (DIN-EN 60068-2-6)	20 g / 20 ... 500 Hz in 3axes, 2 directions and 10 cycles each	
Protection class (DIN-EN 60529)	IP65	
Material	Aluminum housing	
Weight	approx. 30 g (without cable), approx. 110 g (incl. cable)	
Control and display elements	Select button: zero, teach, factory settings web interface for setup ⁵ ; 2 x color LEDs for power / status	

FSO = full scale output

SMR = start of measuring range, MMR = mid of measuring range, EMR = end of measuring range

The specified data apply to white, diffuse reflecting surfaces (Micro-Epsilon reference ceramic for ILD sensors)

- 1) Factory setting 1 kHz, modifying the factory settings requires the IF2001/USB converter (see accessories)
- 2) Measuring rate 1 kHz, median 9
- 3) Illuminant: light bulb
- 4) D/A conversion with 12 bit
- 5) Connection to PC via IF2001/USB (see accessories)

4. Delivery

4.1 Unpacking, Included in Delivery

- 1 Sensor ILD 1220
- 1 Assembly instruction
- 1 Calibration protocol
- Accessories (2 pieces screw M2 and 2 pieces washer)

- ➡ Carefully remove the components of the measuring system from the packaging and ensure that the goods are forwarded in such a way that no damage can occur.
- ➡ Check the delivery for completeness and shipping damage immediately after unpacking.
- ➡ If there is damage or parts are missing, immediately contact the manufacturer or supplier.

See Appendix for further accessories, see Chap. [A 1](#).

4.2 Storage

Temperature range storage: -20 ... +70 °C (-4 °F ... +158 °F)

Humidity: 5 - 95 % (non-condensing)

5. Installation

5.1 Notes for Operation

5.1.1 Reflection Factor of the Target Surface

In principle the sensor evaluates the diffuse part of the reflected laser light.




Fig. 5 Reflection factor of the target surface

A statement concerning a minimum reflectance is difficult to make because even a small diffuse fraction can be evaluated from highly reflecting surfaces. This is done by determining the intensity of the diffuse reflection from the CMOS signal in real time and subsequent compensation, see Chap. 3.2. Dark or shiny objects being measured, e.g. black rubber, may require longer exposure times. The exposure time is dependent on the measuring rate and can only be increased by reducing the sensor's measuring rate.

5.1.2 Error Influences

5.1.2.1 Light from other Sources

Thanks to their integrated optical interference filters the optoNCDT 1220 sensors offer outstanding performance in suppressing light from other sources. However, this does not preclude the possibility of interference from other light sources if the objects being measured are shiny and if lower measuring rates are selected. Should this be the case it is recommended to use suitable shields to screen the other light sources. This applies in particular to measurement work performed in close proximity to welding equipment.

5.1.2.2 Color Differences

Because of intensity compensation, color difference of targets affect the measuring result only slightly. However, such color differences are often combined with different penetration depths of the laser light into the material. Different penetration depths then result in apparent changes of the measuring spot size. Therefore color differences in combination with changes of penetration depth may lead to measuring errors.

5.1.2.3 Temperature Influences

When the sensor is commissioned a warm-up time of at least 20 minutes is required to achieve uniform temperature distribution in the sensor. If measurement is performed in the micron accuracy range, the effect of temperature fluctuations on the sensor holder must be considered. Due to the damping effect of the heat capacity of the sensor, sudden temperature changes are only measured with delay.

5.1.2.4 Mechanical Vibration

If the sensor is to be used for resolutions in the μm to sub- μm range, special care must be taken to ensure stable and vibration-free mounting of sensor and target.


5.1.2.5 Movement Blurs

If the objects being measured are fast moving and the measuring rate is low, it is possible that movement blurs may result. Always select a high measuring rate for high-speed operations, therefore, in order to prevent errors.


5.1.2.6 Surface Roughness

Laser-optical sensors detect the surface using an extremely small laser spot. They also track slight surface unevenness. In contrast, a tactile, mechanical measurement, e.g. using a caliper, detects a much larger area of the measurement object. In case of traversing measurements, surface roughnesses of $5\ \mu\text{m}$ and more lead to an apparent distance change.

Suitable parameters for the averaging number may improve the comparability of optical and mechanical measurements.



Ceramic reference surface



Structured surface

Recommendation for parameter choice:

- The averaging number should be selected in such a way that a surface area the size of which is comparable to those with mechanical measurements is averaged.

5.1.2.7 Angle Influences

Tilt angles of the target in diffuse reflection both around the X and the Y axis of less than 5° only have a disturbing effect with surfaces which are highly reflecting.

These influences have to be explicitly considered when scanning profiled surfaces. Basically the angle behavior of triangulation is liable to the reflectivity of the measuring object surface.






Fig. 6 Measurement errors through tilting with diffuse reflection

5.1.3 Optimizing the Measuring Accuracy



In case of rolled or polished metals that are moved past the sensor the sensor plane must be arranged in the direction of the rolling or grinding marks. The same arrangement must be used for color strips.

Fig. 7 Sensor arrangement in case of ground or striped surfaces



In case of bore holes, blind holes and edges in the surface of moving targets the sensor must be arranged in such a way that the edges do not obscure the laser spot.


Fig. 8 Sensor arrangement for holes and ridges

5.2 Mounting, Dimensions

The optoNCDT 1220 sensor is an optical system for measurements with micrometer accuracy. The laser beam must be directed perpendicularly onto the surface of the target. In case of misalignment it is possible that the measurement results will not always be accurate.

i Make sure it is handled carefully when installing and operating.

► Mount the sensor by means of 2 screws type M3 or by means of through bores for M2 with the screws from the accessories.

Bolt connection				
				
Through length	Screw depth	Screw	Washer	Torque
	Minimum	ISO 4762-A2	ISO 7089-A2	$\mu = 0.12$
mm	mm	2 pieces		Nm
20	5.0	M2 x 25	A2.2	0.5



Direct fastening			
			
Screw depth		Screw	Torque
Minimum	Maximum	ISO 4762-A2	$\mu = 0.12$
mm	mm	2 Stück	Nm
4.8	20	M3	1.0

Fig. 9 Mounting conditions

The bearing surfaces surrounding the through-holes (mounting-holes) are slightly raised.

i Mount the sensor only to the existing holes on a flat surface. Clamps of any kind are not permitted. Do not exceed torques.



ILD 1220-		10	25	50	100	200	500
MR	mm	10	25	50	100	200	500
SMR	mm	20	25	35	50	60	100
EMR	mm	30	50	85	150	260	600
Y	mm	10	21	28	46	70	90

The indicated free space in the reception area, see Fig. 10, has to be kept clear from foreign objects and extraneous light of other laser sensors at least until the end of measuring range.


- MR = Measuring range
- SMR = Start of measuring range
- MMR = Mid of measuring range
- EMR = End of measuring range
- FSO = Full scale output

Fig. 10 Dimensional drawing and free space for optics and optical free space

A: 2x M3 for direct fastening or
2x M2 for bolt connection

5.3 Indicator Elements at Sensor

LED State	Meaning
green	Measuring object within sensor range
yellow	Mid range
red	Error - e.g. Poor target or out of range
off	Laser off
LED Output	Meaning
green	RS422 measurement value output
yellow	The current output is switched off.
red	Current 4 ... 20 mA measurement value output
off	Sensor off, no supply



The programmable touch key `select` calls up the functions `Reset`, `Teaching` or `zeroing`. By factory default this key is only active for the first 5 minutes after power up. After that it will be automatically locked.

5.4 Electrical Connections

5.4.1 Connection Possibilities for Parametrization





Fig. 11 Connection example on ILD 1220

The periphery devices can be connected to the sensor by the illustrated connections, see Fig. 11. The converter IF2001/USB also supplies the operating voltage (24 V DC) of the sensor. Power to the converter is supplied e. g. by the optional power supply PS 2020.

Peripheral	Sensor channels	Interface
IF2001/USB, RS422 USB converter	one	RS422
SPS, ILD 1220 or the like	---	Functional input: trigger
Switch, key, PLC or the like	---	Switching input laser On/Off

Fig. 12 Max. sensor channels on the peripheral devices

5.4.2 Pin Assignment



The shielding of the cable is connected to the sensor housing. The sensor cable is not cable carriers suitable. One end is molded on the sensor, the other end has free leads with ferrules.


ILD1220 with open ends

Signal	Color sensor cable	Description	Specification, Wiring
RS422 Rx+	green	Serial input	Internally terminated with 120 Ohm
RS422 Rx-	yellow		
RS422 Tx+	gray	Serial output	Terminate externally with 120 Ohm
RS422 Tx-	pink		
+ U_B	red	Supply voltage	11 ... 30 VDC, typ. 24 VDC, $P < 2 \text{ W}$
Laser on/off	black	Switch input	Laser is active, if input is connected with GND
Functional input	violet		Trigger, Zero, Teaching
Error	brown	Digital output	$I_{\max} = 100 \text{ mA}$, $U_{\max} = 30 \text{ VDC}$, Programmable switching characteristic: (NPN, PNP, Push-Pull)
I_{OUT}	white	4 ... 20 mA	$R_{\text{Load}} = 250 \text{ Ohm}$: $U_{\text{OUT}} 1 \dots 5 \text{ V}$ with $U_B > 11 \text{ V}$ $R_{\text{Load}} = 500 \text{ Ohm}$: $U_{\text{OUT}} 2 \dots 10 \text{ V}$ with $U_B > 17 \text{ V}$
GND	blue	Ground potential	Supply and signal ground
Connector housing	Shield	Sensor housing	Connect with potential equalization

5.4.3 Supply Voltage

Nominal value: 24 V DC (11 ... 30 V, $P < 2 \text{ W}$).

- Only turn on the power supply after wiring has been completed.
- Connect the inputs “red” and “blue” at the sensor with a 24 V voltage supply.



Wire color	Supply
red	$+U_B$
blue	Ground


Use the supply voltage for measurement instruments only and not for drive units or similar sources of pulse interference at the same time. MICRO-EPSILON recommends using an optional available power supply unit PS2020 for the sensor.

Fig. 13 Connection of supply voltage

5.4.4 Laser on

The measuring laser on the sensor is activated via an HTL switch input. This is advantageous if the sensor has to be switched off for maintenance or similar. Switching can be done with a transistor (for example open collector in an optocoupler) or a relay contact.

i If the black and blue wire are not connected, the laser is off.



There is no external resistor for current limiting required. Connect the black wire with the blue wire for permanent „Laser on“. Reaction Time for Laser-On: Correct measuring data are sent by the sensor approximately 1 ms after the laser was switched on.


Fig. 14 Electrical wiring for laser off

5.4.5 RS422 Connection with USB Converter IF2001/USB

Cross the lines for connections between sensor and PC.

i Disconnect or connect the D-sub connection between RS422 and USB converter when the sensor is disconnected from power supply only.

Sensor		End device (converter) Type IF2001/USB from MICRO-EPSILON
Signal	Sensor cable	
Tx +	grey	Rx + (Pin 3)
Tx -	pink	Rx -(Pin 4)
Rx +	green	Tx + (Pin 1)
Rx -	yellow	Tx -(Pin 2)
GND	blue	GND (Pin 9)



Symmetric differential signals acc. to EIA-422, not galvanically isolated from supply voltage.

Use a shielded cable with twisted cores.

Fig. 15 Pin assignment IF2001/USB


5.4.6 Analog Output

The sensor provides a current output 4 ... 20 mA.

i The output may not be continuously operated in short circuit operation without load resistor. The short circuit operation leads to durable thermal overload and thus for automatic overload shutdown of the output.

➡ Connect the white and the blue wire on the sensor to a measuring device.

Sensor	
Signal	Sensor cable
I_{OUT}	white
GND	blue



With the adjacent circuit you will get an analog voltage output in the range of 1 ... 5 V.

$R = 250 \text{ Ohm}$:

$U_{OUT} 1 \dots 5 \text{ V at } U_B > 11 \text{ V}$


$R = 500 \text{ Ohm}$:

$U_{OUT} 2 \dots 10 \text{ V at } U_B > 17 \text{ V}$

Fig. 16 Wiring for voltage output

5.4.7 Multifunctional Input

The multifunctional input enables the functions Triggering, Zeroing and Teaching. The function is dependent on the programming of the input and of the time behavior of the input signal.



Input is not galvanically isolated.

24V logics (HTL):

Low level $\leq 2\text{ V}$

High level $\geq 8\text{ V}$ (max 30 V),

Internal pull up resistance, an open input is noticed as High.


Connect the input with GND to trigger the function.

Fig. 17 Electrical wiring for multifunctional input

5.4.8 Digital Output

The switching characteristic (NPN, PNP, Push-Pull, Push-Pull negated) of the digital output (Error) depends on the programming.

The NPN output is e.g. suitable for adjustment to TTL logics with an auxiliary voltage $U_H = +5\text{ V}$. The digital output is protected against reverse polarity, overloading ($< 100\text{ mA}$) and over temperature.



Output is not galvanically isolated.

24V logics (HTL),

$I_{\max} = 100\text{ mA}$,

$U_{H\max} = 30\text{ V}$ saturation voltage at

$I_{\max} = 100\text{ mA}$:

Low $< 2.5\text{ V}$ (output - GND),

High $< 2.5\text{ V}$ (output - $+U_B$)


Fig. 18 Electrical wiring digital output

Switching characteristic		
Description	Output active (error)	Output passive (no error)
NPN (Low side)	GND	appr. $+U_H$
PNP (High side)	$+U_B$	appr. GND
Push-Pull	$+U_B$	GND
Push-Pull, negated	GND	$+U_B$

Fig. 19 Switching characteristic *digital output*

The digital output is activated when measuring object is missing, measuring object too close/too far or when no valid measurement value can be determined.

5.4.9 Sensor Cable



ILD 1220 with open ends

- ➡ Never fall below the bending radius for the sensor cable of 30 mm (fixed) or 60 mm (dynamic).
- **i** The fixed connected sensor cables are not cable carriers suitable.
- **i** Unused open cable ends must be insulated to protect against short circuits or malfunction of the sensor.
- ➡ Avoid excessive pulling to the cables. Provide strain relieves near the connectors when cables > 5 m are vertically free hanging.
- ➡ Connect the cable shield to the potential equalization (PE, protective earth conductor) on the evaluator (control cabinet, PC housing) and avoid ground loops.
- ➡ Never lay signal leads next to or together with power cables or pulse-loaded cables (e.g. for drive units and solenoid valves) in a bundle or in cable ducts. Always use separate ducts.

Recommended strand cross-section for self-made connection cables: $\geq 0.14 \text{ mm}^2$ (AWG 25).

6. Operation

6.1 Getting Ready for Operation

- ▶ Install and assemble the optoNCDT 1220 in accordance with the instructions set out, see Chap. 5.
- ▶ Connect the sensor with the indicator or monitoring unit and the power supply.

The laser diode in the sensor can only be activated if at the input Laser on/off Pin 8 is connected with Pin 12, see Chap. 5.4.4.

Once the operating voltage has been switched on the sensor runs through an initialization sequence. This is indicated by the momentary activation of all the LEDs. Once initialization has been completed, the sensor transmits a „->“ via the RS422 interface. The initialization takes up to 10 seconds. Within this period, the sensor executes the `Reset` or the `Bootloader` command through the key `select` only.

To be able to produce reproducible measurements the sensor typically requires a start-up time of 20 minutes.

If the LED `output` is off, this means that there is no supply voltage.


If the LED `state` is off, this means that the laser light source has been switched off.

6.2 Parameterizing via Web Interface

6.2.1 Preconditions


In the sensor a webserver is implemented. The web interface contains among other things the current settings of the sensor and the periphery. The operation is only possible as long as an RS422 connection to the sensor exists. The sensor is connected to a PC/notebook via a RS422 converter, supply voltage persist.

➡ Start the program SensorTool Vx.x.x.



➡ Click the button `Sensor`.

The program searches for connected ILD1220 sensors on available interfaces.



You need a web browser compatible with HTML5 on a PC/notebook.

➡ Choose the desired sensor. Click on the button `Open Website`.

6.2.3 Access via Web Interface

► Start the web interface of the sensor, see Chap. 6.2.1.

Interactive websites for programming the sensor now appear in the web browser.

Serial number 18110036
Option 000
Measuring range 10.00mm

optoNCDT1220 MICRO-EPSILON

Search settings Save settings

Measurement configuration

Measuring task
F 3.2551

Signal quality

dynamic
balanced no averaging

Inputs

Signal processing

Measuring rate
1 kHz

Error handling
Error output, no value

Output trigger
Inactive

Outputs

System settings

Distance
3.331 mm

Status
●

Hardware information

Description	Value
Name	ILD1220
Serial number	18110036
Option	000
Article	4120260
Cable head	Wire
Measuring range	10.00mm
Version	001.039
Boot-version	001.006
BuildID	543
Timestamp	20190211_104540


The order of the menu items corresponding to the internal signal processing in the sensor.

The appearance of the web-sites can change dependent of the functions. Each page contains descriptions of parameters and so tips for filling the website.

The sensor is active and supply measurements with a low output rate.

Fig. 20 First interactive web-site after selection of the web interface

By clicking the button ► in the area **Measurement configuration**, the change between the saved configurations (presets) for different measuring object surfaces (targets) is done. Choosing a target causes a predefined configuration of the settings which achieves the best results for the chosen material. In delivery state, only the **Standard** preset is available.




Preset Standard

The measuring configuration is factory-set for ceramics and metals.

Setups

You can store the measuring settings in a setup and activate them in the sensor at any time.

If you use the `Standard` preset, changes on the settings are possible with the `Signal quality` slider.



Averaging

- balanced
- moving, 64 values
- dynamic
- Median, 9 values
- no averaging

Description

In the area `Signal quality` you can switch between three given basic settings (balanced, dynamic and no averaging).

The area `System configuration` displays the current settings e. g. for unit and access authorization in blue lettering.

i After programming all the settings are to be stored permanently in a set of parameters. The next time you turn on the sensor they are available again. Therefore use the button `Save settings`.

6.3 Timing, Measurement Value Flux

The sensor requires three cycles for measurement and calculation without triggering:

Each cycle takes $1000\ \mu\text{s}$ at a measuring rate of 1 kHz. The measured value N is available at the output after three cycles. The delay between acquisition and output is therefore $3000\ \mu\text{s}$. As the processing in the cycles occurs parallel, after another $1000\ \mu\text{s}$, the next measured value $(N+1)$ is output.

7. Set Sensor Parameter

7.1 Preliminary Remarks to the Adjustments

You can program the optoNCDT 1220 using the sensorFINDER tool and the Web interface.

i If you do not save the programming permanently in the sensor, you lost the settings after turning off the sensor.

7.2 Overview Parameter

The following parameters can be set or changed in the optoNCDT 1220, see tab *Settings*.

Inputs	Multifunction input, Key function
Signal processing	Measuring rate, Error handling, Triggering (Data output)
Outputs	RS422, Analog output, Switching output
System settings	Unit on website, Key lock, Load & Store, Import & Export, Access authorization, Sensor reset (factory settings)

7.3 Inputs

7.3.1 Overview Functions

➡ Go to the `Settings` menu.

Multifunctional input	<i>Zeroing</i>	<i>High / Low</i>	<i>Sets the function of the switching input. The Trigger influences export of a measurement value. Zeroing set the current measurement value to half of the analog output values. Teaching scales the analog output. HTL is defined as active input level.</i>
	<i>Trigger In</i>	<i>High / Low</i>	
	<i>Teaching</i>		
	<i>Inactive</i>		
Key function	<i>Zeroing</i>		<i>Sets the function of the sensor key. Inactive means keylock.</i>
	<i>Teaching</i>		
	<i>Inactive</i>		

7.3.2 Zeroing

The zero setting function set the output value to half of the analog output values or to zero (digital value in the web interface). The output range is moved thereby. This function makes sense, for example, for several adjacent measuring sensors or in the case of the thickness and planarity measurement.

Zero setting is used to compensate mechanical tolerances in the measurement setup of the sensors or for relative measurements. When zeroing the sensor's characteristic is parallel displaced.

Sequence for Zeroing:

➡ Bring target and sensor in the desired position together.

➡ Trigger the zero setting function via the hardware input or the button on the sensor.

After zero setting, the sensor will provide new readings relative to the measurement value during zero setting.

i

Zeroing requires that a target is within the measurement range.

Zeroing has an influence on the analog and digital output.

7.3.2.1 Zeroing with Select Key




Fig. 22 Flow chart for zeroing (key select)




Fig. 23 Flow chart for the return of zero setting

- 1) The key `Select` remains without effect since key lock is active.
- 2) The zeroing is not applied when LED `State` is red, flash frequency 8 Hz for 2 s.

i The key `Select` is locked according to factory settings after expiry of 5 min. You can unlock the keylock e.g. via the web interface, see Chap. 7.6.3.

The function Zeroing can be used several times in succession. Between repetition of the function Zeroing a brake of 1 s is necessary. The function Zeroing can also be combined with the multifunctional input.

7.3.2.2 Zeroing with Hardware Input




Fig. 24 Flow chart for zeroing (hardware input)




Fig. 25 Flow chart for the return of zero setting

The function zeroing can be applied successive in several times. Between repeating the zeroing function a pause of 1 s is required. The zeroing function can also be combined with the `select` key.

1) The zeroing is not applied when LED State is red, flash frequency 8 Hz for 2 s.

i A pulse can be made via the functional input (violet wire sensor cable). Details of the hardware input can be found in the electrical connections, see Chap. 5.4.7.

7.4 Signal Processing

7.4.1 Preliminary Remark

➡ Go to the menu `Signal processing` in the vertical navigation.

In the right part of the display you can find references to the chosen setting.

All settings are applied immediately.

7.4.2 Measuring Rate

The measuring rate indicates the amount of measurements per second.

➡ Choose the desired measuring rate.

Measuring rate	250 Hz / 500 Hz / 1 kHz	<i>Use a high measuring rate with light and matt measuring objects. Use a low measuring rate with dark and shiny measuring objects (e.g. black lacquered surfaces) to improve the measuring result.</i>
----------------	-------------------------	---

With a maximum measuring rate of 1 kHz the CMOS element is exposed 1000 times per second. The lower the measuring rate, the higher maximum exposure time.

Measuring rate is set to 1 kHz ex works.

7.4.3 Error Handling

Error handling adjusts the behavior of the analog output and the RS422 interface in the event of an error.

Error handling	<i>Error output, no value</i>	<i>Analog output supplies 3 mA instead of the measurement value. The RS422 interface outputs an error value.</i>	
	<i>Retain last value infinitely</i>	<i>Analog output and RS422 interface stick to the latest valid value.</i>	
	<i>Retain last value</i>	1 ... 1024	Value

If no valid measurement value can be detected, an error is output. If this disrupts further processing, you can alternatively hold the last valid value over a specific period of time i.e. it can be output again. After expiry of the chosen number an error value is output.

7.4.4 Triggering

7.4.4.1 General

The optoNCDT 1220 measurement output is controllable through an external trigger signal or a command. Triggering affects the analog and digital output. The measurement value at the time of triggering is output delayed, see Chap. 6.3.

- Triggering does not influence the timing so that between the trigger event (level change) and the start of output always lie 3 cycles + 1 cycle (Jitter).
- The multifunctional input is used as external trigger input, see Chap. 5.4.7.
- Factory setting: no triggering, the sensor starts data transmission right after start-up.
- Pulse duration of the "Trigger in" signal must be at least 50 μ s.

<i>Output trigger</i>	<i>Level</i>				<i>A continuous measurement task is following as long as the chosen level remains the same. Choice of level, see Chap. 7.3. Pulse duration must be at least a cycle time. The following pause must be at least a cycle time..</i>
	<i>Edge</i>	<i>infinite</i>			<i>Edge selection, see Chap. 7.3. "0" end trigger, "1 ... 16382" values per trigger, "16383" endless trigger</i>
		<i>manual</i>	<i>Number</i>	<i>Value</i>	
<i>Inactive</i>					<i>No triggering</i>

Valid with triggering:

$$f_T < f_M \quad f_T \quad \text{Trigger frequency}$$

$$f_M \quad \text{Measuring rate}$$

Implemented trigger conditions:

Level triggering with high level / low level.

Continuous measurement input or output, as long as the selected level is applied. Then stops the data output.

The pulse duration must be at least one cycle time. The subsequent break must also be at least one cycle time.




Fig. 26 High trigger level (above) with analog output A_0 and digital output signal D_0 (below)

Edge triggering with rising or falling edge.

Starts measured value acquisition or output as soon as the chosen edge is applied to the trigger input. The sensor outputs a fixed number of measurement values when trigger conditions have been met. Value range from 1 ... 16383. After termination of data output the analog output sticks to the last value (sample & hold).

Pulse duration must be at least 50 μ s.




Fig. 27 Trigger edge HL (above) with analog output A_0 and digital output signal D_0 (below)

7.4.4.2 Value Output Trigger

Measurement values are calculated continuously and independently of the trigger event. A trigger event simply triggers the value output via a digital interface. Therefore, any values measured immediately before the trigger event are included in calculating mean values (averages).

7.5 Outputs

7.5.1 Overview

RS422	Baud rate	9.6 / 19.2 / 56.0 / 115.2 / 230.4 ... / 1000 kBps		Transmission rate with binary data format.	
	Output data	Distance / Measurement counter		The data which are provided for the transmission are to activate with the checkbox.	
Analog output	Standard scale			Start of measuring range 4 mA, end of measuring range 20 mA	
	Two-point scale	Minimum value	Value	Always 2 points which mark the start and end of a new measuring range are taught. Reversal of the output signal is possible with two-point scaling.	
		Maximum value	Value		
Switching output	Inactive				
	Measuring range	NPN / PNP / PushPull / PushPullNeg		The switching output is switched when the received signal is not (entirely) in evaluation range (ROI).	
	Analog range	NPN / PNP / PushPull / PushPullNeg		The switching output switches when the scaled analog range is exceeded.	
	Limit monitoring	NPN / PNP / PushPull / PushPullNeg		The error output switches when the limit value is exceeded.	
		Limit mm/inch	Value		
		Hysteresis mm/inch	Value		Value by which the measured value must fall short of the limit value to deactivate the switching output.
Minimum holding period		Value		Indicates in 1 ... 1000 ms how long the switching output must be active at least when the limit value is exceeded. This time period starts when the limit value is exceeded.	
Output interface	Analog / RS422			Selects the used interface. If the RS422 interface is used, signal graphs cannot be shown by the web interface. If the analog output is used, signal graphs can be shown by the web interface, too.	

7.5.2 Digital Output, RS422

7.5.2.1 Values, Ranges

The digital measuring values are being output as unsigned digital values (raw values). 16 or 18 bits per value are being transmitted. Subsequently you can find a compilation of output values and the conversion of the digital value.

Value	Length	Variables	Value range	Formula
Distance (without Mastering)	16 bits	x = digital value	[0; <643] SMR reserve [643; 64887] measuring range [>64887; 65520] EMR reserve	$d \text{ [mm]} = \frac{1}{100} \left(\frac{102}{65520} x - 1 \right) * MR \text{ [mm]}$
		MR = measuring range [mm]	{10/25/50/100/200/500}	
		d = distance [mm]	[-0.01MR; 1.01MR]	
Distance (with Mastering)	18 bits	x = digital value	[0; 229320]	$d \text{ [mm]} = \frac{1}{100} \left(\frac{102}{65520} x - 51 \right) * MR \text{ [mm]}$
		MR = measuring range [mm]	{10/25/50/100/200/500}	
		MP = master position [mm]	[0; MR]	
		MV = master value [mm]	[0; 2MR]	
		d = distance [mm]		
		MV < MP - 0.5MR:	[-0.5MR + MV; MR - MP + MV]	
		MV ≥ MP - 0.5MR:	[-MP + MV; MR - MP + MV]	
Measurement counter	18 bits	x = digital value	[0; 262143]	


Additional information transmitted in the distance value

Distance value	Description	Distance value	Description
262075	data amount too big for selected baud rate	62080	measurement value can not be calculated
262076	no peak available	262081	peak is too large
262077	peak before the measurement range (MR)	262082	Laser is off
262078	peak behind the measurement range (MR)		


7.5.2.2 Characteristics Digital Output

Measurements are coded with 18 bit, if the based on zero setting or mastering. The master value itself can accept the double measuring range. The examples below show the digital output behavior of an ILD1220-50 with 50 mm measuring range.


Target at 16 % measuring range




Target at 60 % measuring range




Target at 60 % measuring range




➡ Zero setting (master value = 0 mm)



➡ Zero setting (master value = 0 mm)



➡ Set master value 10 mm



Digital minimum reached at 10 % MR

Mastering or zero setting is done with the MASTERMV ASCII command, see Chap. [A 3.3.8.3](#).




Fig. 28 Digital values without zero setting or mastering

➡ Set target at 80 % measuring range (40 mm), set master value 100 mm




Fig. 29 Digital values of an ILD1320-50 with mastering, master value 100 mm

7.5.3 Analog Output Scaling

7.5.3.1 Output Scaling

- Max. output range: 4 mA ... 20 mA
- Output gain ΔI_{OUT} : 16 mA = 100 % MR
- Error value: 3.0 mA ($\pm 10 \mu\text{A}$)

The teaching scales the analog output (4 to 20 mA) for a part of the measuring range. This allows you to optimize the resolution for the analog measurement range. Only the current and error output will be affected by the 2 point calibration. Therefore you define a new start and end for the measurement range. This teaching procedure can be performed live via the `select` key, the multifunctional input or via the webinterface.

i With a user defined output scaling you can use the error output, see Chap. 5.4.8, as a programmable limit switch.

The measurement object positions for `Teach 1` (minimum value) and `Teach 2` (maximum value) have to differ from each other.

The teaching process requires a valid measuring signal. The teaching process is terminated at

- no target,
- target not evaluated,
- to close to the sensor - beyond SMR or
- to far from the sensor - beyond EMR.




Fig. 30 Default characteristic (black), reverse, user defined characteristic (red)

7.5.3.2 Output Scaling with Key Select




Fig. 31 Flow chart for output scaling




Fig. 32 Flow chart for the return of output scaling

If the key `Select` is pressed longer than 10 s or not within the timeframe while doing the return of the output scaling, an error is shown via `State LED`. In this case the `State LED` is blinking red with 8 Hz for 2 s.

7.5.3.3 Output Scaling via Hardware Input

Scaling of the analog output can be made via an impulse at the functional input, the violet wire on the sensor cable.




Fig. 33 Flow chart for output scaling




Fig. 34 Flow chart for the return of output scaling

7.5.3.4 Calculation of Measuring Value using Analog Current

Current output (without zeroing, without teaching)

Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 4)}{16} * MR \text{ [mm]}$
MR = measuring range [mm]	{10/25/50/100/200/500}	
d = distance [mm]	[-0,01MR; 1,01MR]	

Current output (with zeroing), reference value is midrange

Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 12)}{16} * MR \text{ [mm]}$
MR = measuring range [mm]	{10/25/50/100/200/500}	
ZP = zero position [mm]	[0; MR]	

Current output (with teaching)

Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 4)}{16} * n \text{ [mm]} - m \text{ [mm]} $
MR = measuring range [mm]	{10/25/50/100/200/500}	
m, n = teachig area [mm]	[0; MR]	
d = distance [mm]	[m; n]	

Current output (with zeroing and teaching)


Variables	Value range	Formula
I_{OUT} = current [mA]	[3,8; <4] SMR reserve [4; 20] measuring range [>20; 20,2] EMR reserve	$d \text{ [mm]} = \frac{(I_{OUT} \text{ [mA]} - 12)}{16} * n \text{ [mm]} - m \text{ [mm]} $
MR = measuring range [mm]	{10/25/50/100/200/500}	
ZP = zero position [mm]	[0; MR]	
m, n = teaching area [mm] ¹	[0; MR]	
d = distance [mm]	[m; n]	

1) If one of the teach points (m, n) is outside the measuring range (MR) due to zeroing, the sensor outputs an error message.


7.5.3.5 Characteristics Distance Value and Analog Output

The zero setting function set the analog output on half of the output range independent on the zero setting position, thus 12 mA. The examples below show the current output and the distance value behavior of an ILD1220-50 with 50 mm measuring range.


Target at 16 % measuring range



Target at 60 % measuring range




➡ Zero setting




Analog maximum reached at 66 % MR

➡ Zero setting



Analog minimum reached at 10 % MR

MR = measuring range, SMR = start of measuring range, EMR = end of measuring range



Zero setting point	Out min	Out max
16 % (8 mm)	9.44 mA (-8 mm)	20.0 mA (33 mm)
60 % (30 mm)	4.00 mA (-15 mm)	18.40 mA (30 mm)


Fig. 35 Analog output with zero setting, measuring range 50 mm

7.5.3.6 Zeroing and Teaching Analog Output


Proceed as follows:

1. Zero setting, menu Inputs
2. Teach output, menu Outputs

The zero setting function set the analog output on half of the output range, see Chap. 7.5.3.5.



- ▶ Target at 60 %, zero setting
- ▶ Set minimum (m) 20 mm and maximum (n) 40 mm



i With $n < m$ generates an inverse characteristic.




Fig. 36 Analog output characteristic after zero setting and scaling with an ILD1220-50

7.5.4 Switching Output

The switching output can be used for error or limit value monitoring of the output value.

Measuring range	Target outside the measuring range, target is absent or inappropriate target (too dark, metallic polished, insufficient reflection).
Analog range	If the distance is outside the scaled analog range, the switching output is activated.
Limit value	If the value exceeds a defined limit, the switching output is activated.

The switching output is activated depending on the set switching behavior, see Chap. 5.4.8.




Fig. 37 Switching output with function limit value, switching behavior (NPN)

When exceeding the limit value, the switching output is activated (conductive) and is then deactivated again when the next hysteresis value is not reached.

The switching output with function `measuring range` or `limit value` is independent of the analog output.

EMR = End of measuring range

LV = Limit value

HV = Hysteresis value

SMR = Start of measuring range

7.6 System Settings

7.6.1 General

After programming all the settings are to be stored permanently in a set of parameters. The next time you turn on the sensor they are available again.

7.6.2 Unit, Language

The web interface promotes the units millimeter (mm) and inch when displaying measuring results.

You can choose German, English or Chinese in the web interface. You can change language in the menu bar.




Fig. 38 Language selection in the menu bar

7.6.3 Keylock

The function keylock for the key *Select*, see Chap. 5.3 prevents unauthorized / unintended performing of the key functions. Keylock is always activated when user level *User* is chosen. Keylock can only be deactivated in user level *Expert*. If an expert logs in the system, keylock on the sensor is automatically unlocked.

Key lock	<i>Automatic</i>	<i>Range from 1 ... 60 [min]</i>	Value	<i>Keylock starts after expiry of defined time. Clicking the button <i>Refresh</i> prolongs the timeframe until keylock starts.</i>
	<i>Active</i>			<i>The key <i>Select</i> is deactivated independent of the user level.</i>
	<i>Inactive</i>			<i>The key <i>Select</i> is active independent of the user level.</i>

Grey shaded fields require a selection.

Dark-bordered fields require you to specify a value.

7.6.4 Load, Save

All settings to the sensor can be saved permanently in one application program, a so called setup.





Fig. 39 Administration of application programs


Administer setups in the sensor, possibilities and procedure			
Save settings	Activate existing setup	Save changes in active setup	Define setup after booting
Menu New setup	Menu Load & Save	Menu bar	Menu Load & Save
<p>➡ Enter the name for the setup into the field <input style="width: 100px; border: 1px solid #ccc;" type="text" value="Individual setup name"/> , e.g. rubber 1.05 and click the button Save.</p>	<p>➡ Click on the setup with the left mouse button.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Load.</p>	<p>➡ Click on the button</p> <div style="text-align: center;">  </div>	<p>➡ Click on the setup with the left mouse button.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Favorite.</p>

Exchange setup with PC/notebook, possibilities	
Save setup on PC	Load setup from PC
Menu Load & Save	Menu Load & Save
<p>➡ Click on the setup with the left mouse button, area A.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Export.</p>	<p>➡ Click on Create setup with the left mouse button.</p> <p>The dialog Setup management opens.</p> <p>➡ Click on the button Search.</p> <p>A Windows dialog for file selections opens.</p> <p>➡ Choose the desired file and click on the button Open.</p> <p>➡ Click the button Import in the setup management.</p>

7.6.5 Import, Export

A set of parameters covers current settings, setup(s) and the initial setup when booting the sensor. The menu `Import & Export` enables easy exchange of sets of parameters with a PC/notebook.

Exchange set of parameters with PC/notebook, possibilities	
Save set of parameters on PC	Load set of parameters from PC
Menu <code>Import & Export</code>	Menu <code>Import & Export</code>
<p>➡ Click on the button <code>New set of parameters</code> with the left mouse button.</p> <p>The dialog <code>Choose setups for export</code> opens.</p> <p>➡ You arrange a set of parameters by selecting/deselecting the check boxes.</p> <p>➡ Click on the button <code>Transmit file</code>.</p> <p>A Windows dialog for file transmission opens.</p> <p>➡ Confirm the dialog with <code>OK</code>.</p> <p>The operating system stores the set of parameters in the area <code>Download</code>.</p> <p>File name for the following example is <code><... \Downloads\ILD1220_50BASICSETTINGS_MEASSETTINGS_SCHALE_T1...SETTING_Rubber 1.05.JSON></code></p>	<p>➡ Click on the button <code>Search</code>.</p> <p>A Windows dialog for file selection opens.</p> <p>➡ Choose the desired file and click on the button <code>Open</code>.</p> <p>The dialog <code>Choose setups for import</code> opens.</p> <p>➡ You define actions to be made by selecting/deselecting the check boxes.</p> <p>➡ Click on the button <code>Transmit file</code>.</p>



A security query, see adjacent figure, helps to avoid that an existing setup is inadvertently overwritten during import.

Options during import:

Overwrite existing setups (with the same name)

Apply settings of the imported boot setup

7.6.6 Access Authorization


The assignment of a password prevents unauthorized changing of settings on the sensor. When delivered, the password protection is not enabled. The sensor operates in the user level *Professional*. The password protection should be enabled after configuration of the sensor. The default password for the expert level is 000.

- i** The default password or a user-defined password is not changed by a software update.
- i** The professional password is independent of the setup and is therefore not together loaded or saved with the setup.

The following functions are available for the user:

	User	Professional
Password required	no	yes
Viewing settings, signal processing, outputs, system settings	yes	yes
Changing settings, signal processing, outputs, system settings	no	yes
Changing password	no	yes
Setting factory setting	no	yes

Fig. 40 Rights in the user hierarchy



Type in the default password 000 or a user-defined password in the Password field and confirm with Login.

Change with a click on the Logout button in the mode user.


Fig. 41 Change in the professional user level

The user management allows you to assign a custom password in the `Professional` mode.

Password	<i>Value</i>	<i>Case-sensitive rules are observed for all passwords. Numbers are allowed. Special characters are not allowed. Maximum length is set to 31 characters.</i>
User level when restarting	<i>User / Professional</i>	<i>Specifies the user level, with which the sensor starts after the re-starting. For this purpose, MICRO-EPSILON recommends the selection <code>user</code>.</i>

After configuration of the sensor the password protection is to be activated. Please note the password for later reference.

 Grey shaded fields require a selection.

 Dark-bordered fields require you to specify a value.

8. Digital Interface RS422

The interface RS422 has a maximum baud rate of 1 MBaud. The factory-set baud rate is 921.6 kBaud.

Data format: Measurement values in binary format, commands as an ASCII string.

Interface parameter: 8 Data bits, no parity, one stop bit (8N1).



Disconnect or connect the D-sub connection between RS422 and USB converter when the sensor is disconnected from power supply only.

8.1 Measurement Data Format

16¹ or 18 bits are transmitted per output value, see Chap. 7.5.2. An output value is divided into three bytes that differ in the two most significant bits. The transmission of additional output values is optional.

Output value 1 / additional:

L-Byte	0	0	D5	D4	D3	D2	D1	D0
M-Byte	0	1	D11	D10	D9	D8	D7	D6
H-Byte	1	0 ²	0 ³	0 ³	D15	D14	D13	D12

Output sequence: L-Byte, M-Byte, H-Byte.

1, 3) Error values are coded with 18 Bit.

2) Bit 7 in the H byte is set to 0 for the last output value. This simultaneously represents the identifier of a new block. With all previous output values in the same block, the 7th is in the H byte 1. Depending on the measuring rate, baud rate and output data rate output all data can be output in one block. If data output is not possible, a run-time error will be output. Use the command GETOUTINFO_RS422 to query for data selection and output sequence.

8.2 Conversion of the Binary Data Format

For conversion purposes the H-Byte, M-Byte and L-Byte must be identified on the basis of the two first bits (flag bits), the flag bits deleted and the remaining bits compiled into a 16 or 18 bit data word.

Result of conversion:

D17	D16	D15	D14	D13	D12	D11	D10	D9	D8	D7	D6	D5	D4	D3	D2	D1	D0
-----	-----	-----	-----	-----	-----	-----	-----	----	----	----	----	----	----	----	----	----	----

Conversion must be done in the application program. D16 and D17 are among others used for interpretation of error codes or e.g. for the measurement counter.

i The sensor continues to deliver measurement values to the RS422 output even while communicating with the sensor.

For the data transmission with a PC the MICRO-EPSILON IF2001/USB is suitable. The IF2001/USB combines the three bytes for the data word and saves them in the FIFO. The 18 bits are used for measurement values and error values. For further information, please refer to the descriptions of the IF2001/USB interface card and associated MEDAQlib driver program.

You will find the latest program routine at: www.micro-epsilon.com/link/software/medaqlib.

9. Cleaning

Cleaning of the protective screens is recommended periodically.

Dry Cleaning

Therefore an optics anti-static brush is suitable or bleeding the screen with dehumidified, clean and oil-free compressed air.

Wet Cleaning

For cleaning the protective screen use a clean, soft, lint-free cloth or lens cleaning paper with pure alcohol (isopropyl).

Never use standard glass cleaner or other cleaning agents.

10. Liability for Material Defects

All components of the device have been checked and tested for functionality at the factory. However, if defects occur despite our careful quality control, MICRO-EPSILON or your dealer must be notified immediately.

The liability for material defects is 12 months from delivery. Within this period, defective parts, except for wearing parts, will be repaired or replaced free of charge, if the device is returned to MICRO-EPSILON with shipping costs prepaid. Any damage that is caused by improper handling, the use of force or by repairs or modifications by third parties is not covered by the liability for material defects. Repairs are carried out exclusively by MICRO-EPSILON.

Further claims can not be made. Claims arising from the purchase contract remain unaffected. In particular, MICRO-EPSILON shall not be liable for any consequential, special, indirect or incidental damage. In the interest of further development, MICRO-EPSILON reserves the right to make design changes without notification. For translations into other languages, the German version shall prevail.

11. Decommissioning, Disposal

➡ Remove the power supply and output cable from the sensor.

Incorrect disposal may cause harm to the environment.

➡ Dispose of the device, its components and accessories, as well as the packaging materials in compliance with the applicable country-specific waste treatment and disposal regulations of the region of use.

12. Service, Repair

If the sensor or sensor cable is defective:

- If possible, save the current sensor settings in a parameter set, see Chap. 7.6.4, to reload them into the sensor after the repair.
- Please send us the affected parts for repair or exchange.


If the cause of a fault cannot be clearly identified, please send the entire measuring system to:

MICRO-EPSILON Optronic GmbH
Lessingstraße 14
01465 Langebrück / Germany
Tel. +49 (0) 35201 / 729-0
Fax +49 (0) 35201 / 729-90
optronic@micro-epsilon.de
www.micro-epsilon.com

Appendix

A 1 Optional Accessories

IF2001/USB



Converter RS422 to USB, type IF2001/USB, inclusive driver, connections: 1 x female connector 10-pin (cable clamp) type Würth 691361100010, 1x female connector 6-pin (cable clamp) type Würth 691361100006

PS2020



Power supply for mounting on DIN rail, input 230 VAC, output 24 VDC/2.5 A

1) One channel with ILD1220 possible only.

A 2 Factory Settings

Password	„000“
Measuring rate	1 kHz
Measuring range	100 % FSO: I = 20 mA
	0 % FSO: I = 4 mA
Error handling	Error output, no measurement

Language	German
Output	Analog current
RS422	921.6 kBaud
Trigger mode	No trigger

Fig. 42 Factory settings standard sensors

Balanced	Moving average with 64 values
Measuring rate	1 kHz

Language	Chinese
RS422	115.2 kBaud

Fig. 43 Factory settings series ILD1220-x(214) sensors




Fig. 44 Flow chart to start a sensor with factory setting

- t_0 : power supply is on
 - $t_1 \dots t_3$: both LEDs signalize the start sequence (red-yellow-green for 1 sec. each)
 - t_2 : key is pressed during start sequence ($t_1 \dots t_3$)
 - t_4 : key is released while the LED state is flashing yellow
- $\Delta t = t_4 - t_2$; Δt (key press period) must be at least 10 sec., max. 15 sec.

A 3 ASCII Communication with Sensor

A 3.1 General

The ASCII commands can be sent to the sensor via the RS422 interface. All commands, inputs and error messages are effected in English.

One command always consists of a command name and zero or several parameters, which are separated by blanks and are completed with LF. If blanks are used in parameters, the parameter must be set in quotation marks.

Example: Switch on the output via RS422

OUTPUT RS422 ←↵

Advice: ←↵ must include LF, but may also be CR LF.

Declaration: LF Line feed (line feed, hex 0A)

CR Carriage return (carriage return, hex 0D)

←↵ Enter (depending on the system System hex 0A or hex 0D0A)

The currently set parameter value is returned, if a command is activated without parameters.

The input formats are:

```
<Command name> <Parameter1> [<Parameter2> [...]]
```

```
<Command name> <Parameter1> <Parameter2> ... <Parameter...>
```

or a combination thereof.

Parameters in []-brackets are optional and require the input of the parameter standing in front. Sequent parameters without []-brackets are to input compulsory, that is, it must not be omitted a parameter.

Alternative inputs of parameter values are displayed separately by „|“, for example the values „a“, „b“ or „c“ can be set for „a|b|c“. Parameter values in <> brackets are selectable from a value range.

Declarations on format:

„a b“	Value of the parameter can be set to the value “a” or “b”.
„ P1 P2“	It requires that both parameters “P1” and “P2” are set.
„ P1 [P2 [P3]]“	The parameters “P1”, “P2” and “P3” can be set, whereby “P2” may only be set, if “P1” is set and “P3” only if “P1” and “P2” are set.
„<a>“	The value of the parameter lies in a value range of “... to ...”, see parameter description.

Parameter values without peak brackets can only assume discrete values, see parameter description.

Parantheses are to be understood as a grouping, that is, for a better articulation „P1 P2 | P3“ is written as „(P1 P2)|P3“.

Example without []:

„PASSWD <Old password> <New password> <New password>“
 - To change the password, all three parameters are to be input.

The output format is:

<Command name> <Parameter1> [<Parameter2> [...]]

The reply can be used again as command for the parameter setting without changes. Optional parameters are only returned, if the returning is necessary. For example, the activated output values are returned by command Data selection additional values. After processing a command always a return and a prompt (“->”) is returned. In the case of an error an error message is before the prompt, that begins with „Exxx“, where xxx is a unique error number. Also warnings („Wxxx“) can be output instead of error messages.

These are analogous to the error messages. In case of warnings the command is executed.

The replies to the commands GETINFO and PRINT are useful for support requests to the sensor, because they contain sensor settings.

A 3.2 Overview Commands

Group	Chapter	Command	Short description
General			
	Chap. A 3.3.1.1	HELP	Help on commands
	Chap. A 3.3.1.2	GETINFO	Request sensor information
	Chap. A 3.3.1.3	LANGUAGE	Determine language of website
	Chap. A 3.3.1.4	RESET	Reboot sensor
	Chap. A 3.3.1.5	ECHO	Switching the command reply, ASCII interface
	Chap. A 3.3.1.6	PRINT	Output of all sensor settings
User level			
	Chap. A 3.3.2.1	LOGIN	Change of user level
	Chap. A 3.3.2.2	LOGOUT	Change to user in the user level
	Chap. A 3.3.2.3	GETUSERLEVEL	User level request
	Chap. A 3.3.2.4	STDUSER	Setting the standard user
	Chap. A 3.3.2.5	PASSWD	Change password
Triggering			
	Chap. A 3.3.3.1	TRIGGER	Selection of trigger mode
	Chap. A 3.3.3.2	MFILEVEL	Selection of level for multifunctional input
	Chap. A 3.3.3.3	TRIGGERCOUNT	Number of measurement values displayed

Interfaces			
	Chap. A 3.3.4.1	BAUDRATE	RS422 setting
	Chap. A 3.3.4.2	UNIT	Selection of measuring unit web interface
	Chap. A 3.3.4.3	MFIFUNC	Selection of function multifunctional input
	Chap. A 3.3.4.4	ERROROUT1	Activate digital output
	Chap. A 3.3.4.5	ERRORLEVELOUT1	Output level digital output
	Chap. A 3.3.4.6	ERRORLIMIT	Limit to activate digital output
	Chap. A 3.3.4.7	ERRORHYSTERESIS	Stable digital output
	Chap. A 3.3.4.8	ERROROUTHOLD	Minimum duration active digital output
Handling of setups			
	Chap. A 3.3.5.1	IMPORT	Load parameter
	Chap. A 3.3.5.2	EXPORT	Export sensor settings
	Chap. A 3.3.5.3	MEASSETTINGS	Load/save measurement settings
	Chap. A 3.3.5.4	BASICSETTINGS	Load/save device settings
	Chap. A 3.3.5.5	SETDEFAULT	Factory settings
Scaling of analog output			
	Chap. A 3.3.6	ANALOGSCALE	Scaling analog output
Key function			
	Chap. A 3.3.7.1	KEYFUNC	Selection of key function
	Chap. A 3.3.7.2	KEYLOC	Selection of keylock

Measurement			
	General		
	Chap. A 3.3.8.1	MEASRATE	Selection of measuring rate
	Chap. A 3.3.8.2	LASERPOW	Selection of laser power
	Chap. A 3.3.8.3	MASTERMV	Mastering / Zeroing
Data Output			
	General		
	Chap. A 3.3.9.1	OUTPUT	Selection measuring value output
	Chap. A 3.3.9.2	OUTHOLD	Setting of error processing
	Chap. A 3.3.9.3	GETOUTINFO_RS422	Request data selection
	Chap. A 3.3.9.4	OUT_RS422	Selection of signal to be transmitted
	Chap. A 3.3.9.5	OUTADD_RS422	Selection of additional values

A 3.3 Commands

A 3.3.1 General Commands

A 3.3.1.1 HELP

Issues a help for every command.

Command without parameter

```
<Command> // Command is executed.
```

Command with parameter.

```
<Command>
```

```
// Show current parameter value
```

```
<Command> <Parameter1> [<Parameter2> [...]]
```

```
// Set parameters, number of parameters varies
```

```
<Command> <Parameter1> <Parameter2> ... <Parameter...>
```

```
// Set parameters, number of parameters is fixed
```

Response to a command

-> Cursor, the sensor waits for an entry

E<dd> <Msg> Error message, execution refused

W<dd> <Msg> Warning

<ddd> Three digits

<Msg> Message

Format

() Group

[] Optional parameters

<> Placeholder

| Alternative

If spaces are used in parameters, the parameters must be placed in quotation marks.

Examples:

```
a|b // Use a or b
a b // Both parameters are required
a [b [c]] // Indefinite number of parameters: a, a b, or a b c
PASSWD <Old password> // In order to change the password, all parameters are required.
<New password> <New password>
```

A 3.3.1.2 GETINFO, Sensor Information

```
GETINFO
```

Request of sensor information. Output see example below:

```
->GETINFO
Name:          ILD1220-10 //Model name sensor, sensor series
Serial:        20110036 //Serial number
Option:        000 //Option number of sensor
Article:       4120260 //Article number of sensor
Cable head:    Wire
Measuring range: 10.00mm //Measuring range of sensor
Version:       001.062 //Version of software
Hardware-rev:  00
Boot-version:  001.006
->
```

A 3.3.1.3 LANGUAGE, Website

LANGUAGE DE | EN < CN | JP

Determines the language for the web interface.

- DE: set language to German
- EN: set language to English
- CN: set language to Chinese
- JP: set language to Japanese

The chosen language setting applies to the website.

A 3.3.1.4 RESET, Boot Sensor

RESET

The sensor is rebooted.

A 3.3.1.5 ECHO, Switching the Command Reply, ASCII Interface

ECHO ON|OFF

Setting the command reply with a ASCII command:

- ON: command reply on, for example <Kdo> ok (or notice of error)
->
- OFF: command reply off, for example ->

A 3.3.1.6 PRINT, Sensor Settings

PRINT

Print serves the output of all sensor settings.

Example of an answer:

```
GETUSERLEVEL PROFESSIONAL      OUTPUT RS422
STDUSER PROFESSIONAL          OUTADD_RS422 NONE
BAUDRATE 921600              GETOUTINFO_RS422 DIST1
UNIT MM                       OUTHOLD NONE
LANGUAGE DE                   ERROROUT1 DIST
MFIFUNC NONE                  ERRORLEVELOUT1 NPN
MFILELEVEL HTL_HIGH          ANALOGSCALE STANDARD
KEYFUNC TEACH                 ERRORLIMIT DIST1 0.000
KEYLOCK AUTO 5 (IS_ACTIVE)    ERRORHYSTERESIS 0.100
MEASRATE 1.000               ERROROUTHOLD 50
TRIGGER NONE
TRIGGERCOUNT 1
```

A 3.3.2 User Level

A 3.3.2.1 LOGIN, Change of the User Level

```
LOGIN <Password>
```

Enter the password to change user level. The following user levels are available:

- USER (standard user): “read-only” access to all elements and graphical display of output values of web surface
- PROFESSIONAL (expert): “read-only” and “write” access to all elements

A 3.3.2.2 LOGOUT, Change into User Level

```
LOGOUT
```

Set user level to USER.

A 3.3.2.3 GETUSERLEVEL, User Level Request

```
GETUSERLEVEL
```

Request current user level

A 3.3.2.4 STDUSER, Set Standard User

```
STDUSER USER|PROFESSIONAL
```

Set standard user who is automatically logged in after system start. Standard user does not change with LOGOUT which means login as standard user is done automatically after the command RESET or power supply of sensor is switched on.

A 3.3.2.5 PASSWD, Change Password

```
PASSWD <Old Password> <New password> <New password>
```

Change password for user level PROFESSIONAL.

Type in the old password followed by the new password (2x). In case the new password is not typed in correctly, an error message is will be displayed. Password may only contain letters from A to Z, no numbers 0 to 9. Watch upper and lower case lettering. The maximum length is limited to 31 characters.

A 3.3.3 Triggering

The multifunctional input also serves as trigger input for measurement output.

A 3.3.3.1 TRIGGER, Selection

TRIGGER NONE | EDGE | PULSE

- NONE: no triggering
- PULSE: level triggering
- EDGE: edge triggering

A 3.3.3.2 MFILELEVEL, Input Pulse Multifunctional Input

MFILELEVEL HTL_HIGH | HTL_LOW

Selection of switching or trigger level for the multifunctional input.

- HTL_HIGH: high active (edge triggering: rising edge, pulse triggering: high active)
- HTL_LOW: low active (edge triggering: falling edge, pulse triggering: low active)

A 3.3.3.3 TRIGGERCOUNT, Number of Displayed Measurement Values

TRIGGERCOUNT NONE | INFINITE | <n>

<1...16382>

Number of displayed measurement values while triggering

- NONE: stop triggering and start continuous output
- INFINITE: start continuous output after first trigger impulse
- <n>: number of displayed measurement values after each trigger impulse n = 1 ... 16382

A 3.3.4 Interfaces

A 3.3.4.1 BAUDRATE, RS422

```
BAUDRATE 9600|19200|56000|115200|128000|230400|256000|460800|691200|921600|
1000000
```

Set the baud rate for the RS422 interface.

A 3.3.4.2 UNIT, Web Interface

```
UNIT MM|INCH
```

Change the measurement display on the websites. The command has no effect on the ASCII interface.

- MM representation in mm
- INCH representation in customs

A 3.3.4.3 MFIFUNC, Function Selection Multifunctional Input

```
MFIFUNC NONE | MASTER | TEACH | TRIGGER
```

Choose function of the multifunctional input.

- NONE: multifunctional input has no function
- MASTER: multifunctional input is master impulse input
- TEACH: multifunctional input is teach input for analog output
- TRIGGER: multifunctional input is trigger input

A 3.3.4.4 ERROROUT1, Activate Error Output

```
ERROROUT1 NONE|DIST|TEACH|LI1
```

Choose error signal of the digital output ERROR.

- NONE: digital ourput deactivated
- DIST: no peak found or beyond measuring range (out of range)
- TEACH: Distance is out of scaled analog range
- LI1: Distance is greater than the limit value (ERRORLIMIT)

A 3.3.4.5 ERRORLEVELOUT1, Output Level Digital Output

```
ERRORLEVELOUT1 NPN|PNP|PUSHPULL|PUSHPULLNEG
```

Choice of output level for ERROROUT1.

- NPN: digital output is active in case of an error
- PNP: digital output is active in case of an error
- PUSHPULL: digital output with high level in case of an error
- PUSHPULLNEG: digital output with low level in case of an error

Wiring of digital output ERROR1, see Chap. 5.4.8.

A 3.3.4.6 ERRORLIMIT

```
ERRORLIMIT DIST1 <upper threshold>
```

Digital output is activated, if the defined value for a measurement is exceeded.

Range: $-2 \dots 2 * \text{measuring range [mm]}$.

A 3.3.4.7 ERRORHYSTERESIS

```
ERRORHYSTERESIS <hysteresis>
```

Digital output is deactivated, if the defined value for a measurement falls below the limit value.

Range: $0 \dots 2 * \text{measuring range [mm]}$.

A 3.3.4.8 ERROROUTHOLD

```
ERROROUTHOLD <hold period>
```

Indicates in ms how long the digital output must be active at least when the limit value is exceeded. This time period starts when the limit value is exceeded. Range: $0 \dots 1000 \text{ [ms]}$.

A 3.3.5 Handling of Setups

A 3.3.5.1 IMPORT

```
IMPORT [FORCE] [APPLY] <ImportData>
```

Import of data in JSON format ¹ to the sensor.

First, the import command returns a prompt (->). Afterwards, data can be sent.

After importing a prompt (->) is returned.

- FORCE: overwriting of measurement settings (= MEASSETTINGS) with the same name (otherwise an error message is returned when using the same name). When importing all measurement settings or device settings (= BASICSETTINGS) FORCE must always be stated.
- APPLY: applying the settings after importing / reading of initial settings.
- ImportData: Data in JSON format

1) JSON format, see https://de.wikipedia.org/wiki/JavaScript_Object_Notation

A 3.3.5.2 EXPORT

```
EXPORT (MEASSETTINGS <SettingName>) | BASICSETTINGS | MEASSETTINGS_ALL | ALL
```

Exporting sensor settings. As a response data is transmitted in JSON format. Finally a prompt occurs.

- MEASSETTINGS: Exports the measurement settings with name <SettingName>
- BASICSETTINGS: Exports only the basic settings
- MEASSETTINGS_ALL: Exports all measurement settings
- ALL: *Exports basic settings and all measurement settings*

A 3.3.5.3 MEASSETTINGS, Load / Save Measurement Settings

MEASSETTINGS <Subcommands> [Name]

Settings of the measurement task.

Loads proprietary presets and one user-specific setting from the sensor or stores one user-specific setup in the sensor.

Subcommands:

- CURRENT: Output of the name of current measurement setting
- PRESETLIST: Listing of all existing presets (names): „Standard“, „Multi-Surface“, „Light Penetration“.
- LIST: Listing of all saved measurement settings (names) “Name1” “Name2” “...”.
- READ <Name>: Loads a preset or a measurement setting from the sensor.
- STORE <Name, new>: Saves the current measurement setting in the sensor.
- DELETE <Name>: Deletes a measurement setting
- RENAME <NameOld> <NameNew> [FORCE]: Renaming a measurement setting. An existing measurement setting can be overwritten with FORCE.
- INITIAL AUTO: Loads the last saved measurement setting at the start of the sensor.
- INITIAL <name>: Loads a named measurement setting at the start of the sensor.
- PRESETMODE: Returns the set signal quality
- PRESETMODE <Mode>: Setting the signal quality. Setting the signal quality is possible only, if a preset was loaded.
 - <mode> = BALANCED|DYNAMIC|NOAVERAGING

Names:

<name> Name of a manufacturer setup or a user-specific setup.

<name new> Name of a user-specific setup. Names must have at least two characters and are limited to max. 31 characters. Letters from A to Z without umlauts and numbers are allowed, the name is case-sensitive. Preset names are not permissible, a name should not begin with “Auto”.

A 3.3.5.4 BASICSETTINGS, Load / Save Device Settings

BASICSETTINGS READ | STORE

- READ: Loads the stored device settings from the sensor.
- STORE: Saves the current device settings in the sensor.

Most of the settings belong to the Measurement settings group. The following commands enable the configuration of the device settings:

- BAUDRATE
- ECHO
- KEYLOCK
- LANGUAGE
- PASSWD
- UNIT

A 3.3.5.5 SETDEFAULT, Default Settings

SETDEFAULT ALL | MEASSETTINGS | BASICSETTINGS

Sets sensor back to default settings.

- ALL: Measurement and device settings are being deleted. The standard preset for the measurement setting or the the default parameter for the device settings are being loaded.
- MEASSETTINGS: Measurement settings are being deleted and the standard preset is being loaded.
- BASICSETTINGS: Device settings are being deleted and the default parameters are being loaded.

A 3.3.6 ANALOGSCALE, Scaling the Analog Output

ANALOGSCALE STANDARD| (TWOPOINT <Minimum value> <Maximum value>)

Setting the two point scaling of the analog output.

- STANDARD: using the measuring range of the sensor
- TWOPOINT: two point scaling within the analog range (4 - 20 mA)
 - Minimum value: measurement value in mm which is matched to the lower analog value (4 mA)
 - Maximum value: measurement value in mm which is matched to the upper analog value (20 mA)

i The minimum value (in mm) can be higher than the maximum value (in mm), see Chap. 7.5.3.

A 3.3.7 Key Function

A 3.3.7.1 KEYFUNC, Choose Key Function

```
KEYFUNC NONE | MASTER | TEACH
```

Choice of key function.

- NONE: key has no function
- MASTER: key is used for mastering
- TEACH: key is used for teaching

A 3.3.7.2 KEYLOCK, Set Keylock

```
KEYLOCK NONE|ACTIVE|AUTO <time>
```

Choice of keylock.

- NONE: key works permanently, no keylock
- ACTIVE: keylock is activated right after reboot
- AUTO: keylock is only activated <time> minutes after reboot
 - <time> range between 1 ... 60 minutes

A 3.3.8 Measurement

A 3.3.8.1 MEASRATE, Measuring Rate

```
MEASRATE 0.25|0.5|1
```

Choice of measuring rate in kHz.

A 3.3.8.2 LASERPOW, Laser Power

```
LASERPOW FULL|OFF
```

- FULL: laser power is set to 100 %
- OFF: laser is switched off

A 3.3.8.3 MASTERMV, Mastering / Zeroing

```
MASTERMV NONE|MASTER <MV>
```

- NONE: completes mastering
- MASTER: sets the current measurement value as a master value
- MV: master value in millimeters; $MV = (0 \dots 2) * \text{measuring range}$, i.e. master value must be within measuring range

In case of master value is 0, the mastering has the same functionality as the zeroing. The parameter MV always operates independently from an input as zeroing during mastering the analog output.

The master command awaits the next measurement value, a maximum of 2 seconds, and masters it. If no measurement value is received within this time, for example, by external triggering, the command returns with the error "E220 Timeout".

The master value is processed with six decimal places.

Note that the output value is limited to 18 bits.

A 3.3.9 Data Output

A 3.3.9.1 OUTPUT, Selection of Measurement Value Output

OUTPUT NONE | RS422 | ANALOG

- NONE: no measurement value
- RS422: output of measurement value via RS422
- ANALOG: analog output of measurement values

A 3.3.9.2 OUTHOLD, Error Processing

OUTHOLD NONE | INFINITE | <n>

Setting the behavior of the measurement value output in case of error.

- NONE: no holding of the last measurement value, output of error value
- INFINITE: infinite holding of the last measurement value
- <n>: holding of the last measurement value on the number of measurement cycles; then an error value is output, n = (1 ... 1024)

A 3.3.9.3 GETOUTINFO_RS422, Request Data Selection

GETOUTINFO_RS422

The command lists all selected output data for the RS422 interface. The sequence shown corresponds to the output sequence.

A 3.3.9.4 OUT_RS422

OUT_RS422 NONE | ([DIST1] [COUNTER])

This command is used to choose the signals for measurement data output via the RS422 interface.

- DIST1: Calibrated distance value
- COUNTER: Measured value counter
- NONE: No value output

A 3.3.9.5 OUTADD_RS422, Selection of Data Additional Values

OUTADD_RS422 NONE | COUNTER

Selection of additional values to be transmitted.

- NONE: no output of additional values
- COUNTER: output of measurement value counter

A 3.4 Error Messages

If an error occurs with a command, the error message is listed.

Error message	Description
E100 Internal error	Internal error code
E104 Timeout	Timeout while mastering.
E200 I/O operation failed	Cannot write data to the output channel.
E202 Access denied	Access denied: Login as expert is necessary.
E204 Received unsupported character	An unsupported character was received
E210 Unknown command	Unknown command rights to small to read).
E214 Entered command is too long to be processed	The entered command with the parameters is too long (greater than 255 bytes).
E220 Timeout, command aborted	Timeout during mastering.
E232 Wrong parameter count	Too high or too small number of parameters.
E234 Wrong or unknown parameter type	A transmitted parameter has a wrong type or a wrong number of parameters were transmitted.
E236 Value is out of range or the format is invalid	The parameter value is out of range of the value range.
E262 Active signal transmission, please stop before	A measurement value transmission is active. Stop the data transmission in order to execute the command.
E320 Wrong info-data of the update	For update only: the header of update data contains an error.
E321 Update file is too large	For update only: update data is too large.
E322 Error during data transmission of the update	For update only: error during update data transmission.
E323 Timeout during the update	For update only: Timeout during the transmission of update data.
E331 Validation of import file failed	The import file is not valid.

E332 Error during import	Error during processing the import data
E333 No overwrite during import allowed	No overwrite of measurement and device settings allowed through import, set the checkbox.
E350 The new passwords are not identical	Password and verification password do not match.
E360 Name already exists or not allowed	The measurement setting name already exists or is not allowed.
E361 Name begins or ends with spaces or is empty	Name for the measurement setting begins or ends with spaces or is empty.
E362 Storage region is full	Number of storable measurement settings is reached.
E363 Setting name not found	Name of the measurement setting to be loaded not found
E364 Setting is invalid	Measurement or device setting is invalid
E602 Master value is out of range	Master value is out of valid range
E616 Software triggering is not active	Software triggering is not active.

Warning	Description
W320 The measuring output has been adapted automatically.	The measuring output has been adapted automatically.



MICRO-EPSILON MESSTECHNIK GmbH & Co. KG
Koenigbacher Str. 15 · 94496 Ortenburg / Germany
Tel. +49 (0) 8542 / 168-0 · Fax +49 (0) 8542 / 168-90
info@micro-epsilon.com · www.micro-epsilon.com
Your local contact: www.micro-epsilon.com/contact/worldwide/

X9751406-B012031MSC
© MICRO-EPSILON MESSTECHNIK